


SS Rack Filter Press



Product Description

We can produce it fully in stainless steel including the structure and filter plate, or only wrap a layer of stainless steel around the rack. It is mainly used in the special industry with strong corrosion or food grade.

We can also equip with feeding pump, belt conveyor, liquid receiving flap, filter cloth water rinsing system, mud storage hopper, etc.

- ✧ The Filter Press is consistent of the rack, filter plate, filter cloth, hydraulic system and electrical system, etc.
- ✧ Material of rack: Carbon steel, wrapped SS, wrapped PP, powder coating.
- ✧ Pressing system: Manual jack pressing, hydraulic pressure automatic pressing.
- ✧ Material of filter plate: PP plate, membrane plate, high pressure filter plate, high temperature filter plate, cast iron filter plate, SS filter plate.

Product Features

A-1. Filtration pressure: 0.6Mpa; 1.0Mpa; 1.3Mpa; 1.6Mpa. (Optional)

A-2. Diaphragm squeezing cake pressure: 1.0Mpa; 1.3Mpa; 1.6Mpa. (Optional)

B. Filtration temperature: 45°C/ room temperature; 65-100°C/ high temperature.(Optional)

C-1. Discharge method - open flow: Faucets need to be installed below the left and right sides of each filter plate, and a matching sink. Open flow is used for liquids that are not recovered.

C-2. Liquid discharge method -close flow: Under the feed end of the filter press, there are two close flow outlet main pipes, which are connected with the liquid recovery tank. If the liquid needs to be recovered, or if the liquid is volatile, smelly, flammable and explosive, dark flow is used.

D-1. Selection of filter cloth material: The PH of the liquid determines the material of the filter cloth. PH1-5 is acidic polyester filter cloth, PH8-14 is alkaline polypropylene filter cloth. The viscous liquid or solid is preferred to choose twill filter cloth, and the non-viscous liquid or solid is selected plain filter cloth.

D-2. Selection of filter cloth mesh: The fluid is separated, and the corresponding mesh number is selected for different solid particle sizes. Filter cloth mesh range 100-1000 mesh. Micron to mesh conversion (1UM = 15,000 mesh---in theory).

E. Rack surface treatment: When the PH value neutral or weak acid base: The surface of the filter press frame is sandblasted first, and then sprayed with primer and anti-corrosion paint. When the PH value is strong acid or strong alkaline, the surface of the filter press frame is sandblasted, sprayed with primer, and the surface is wrapped with stainless steel or PP plate.

F. Diaphragm filter press operation (for choice): Automatic Hydraulic Pressing; Filter cake washing, Automatic Filter Plate Pulling; Filter Plate Vibrating Cake Discharge; Automatic Filter Cloth Rinsing System. Please kindly tell me the functions you need before ordering.

G. Filter cake washing (for choice): When solids need to be recovered, the filter cake is strongly acidic or alkaline; When the filter cake needs to be washed with water, please send an email to inquire about the washing method.

H. Filter press feeding pump (for choice): The solid-liquid ratio, acidity, temperature and characteristics of the liquid are different, so different feed pumps are required. Please send email to inquire.


I. Automatic belt conveyor (for choice): The belt conveyor is installed under the plate of filter press, which is used for transporting the discharged cake after the filter plates have been pulled open. This device is suitable for the project which is not convenient to make the base floor. It can delivery the cake to the designated place, which will reduce much labor work.

J. Automatic dripping tray (for choice): The drip tray is installed under the plate of filter press. During the filtration process, the two plate trays are in a closed state, which can lead the dripping liquid during the filtration and the cloth washing water to the water collector sideways. After the filtration, the two plate trays will be opened to discharge the cake.

K. The filter press cloth water flushing system (for choice): It is installed above the main beam of the filter press, and it is equipped with automatic travelling function, and the filter cloth is automatically rinsed with high pressure water (36.0Mpa) by switching the valve. There are two kinds of structures for rinsing: single-side rinsing and double-side rinsing, in which the double-side rinsing has brushes for good cleaning effect. With the flap mechanism, the rinsing

water can be recycled and reused after treatment to save resources; combined with diaphragm press system, it can get lower water content; assembled frame, compact structure, easy to disassemble and transport.


Feeding process




Filter press ordering instructions

1. Refer to the filter press selection guide, filter press overview, specifications and models, select the model and supporting equipment according to the needs. For example: Whether the filter cake is washed or not, whether the effluent is open or close, whether the rack is corrosion-resistant or not, the mode of operation, etc., must be specified in the contract.
2. According to the special needs of customers, our company can design and produce non-standard models or customized products.
3. The product pictures provided in this document are for reference only. In case of changes, we will not give any notice and the actual order will prevail.


Dimension Drawing



Hoisting diagram of filter press



Filter plates hoisting diagram



Filter Press Model Guidance

Liquid name	Solid-liquid ratio (%)	Specific gravity of solids	Material status	PH value	Solid particle size (mesh)
Temperature (°C)	Recovery of liquids/solids	Water content of filter cake	Working hours/day	Capacity/day	Whether the liquid evaporates or not

Technical parameter

Model	Filter area (m ²)	Plate Size (mm)	Chamber volume (L)	Plate Qty (pcs)	Weight (Kg)	Motor power (KW)	Overall dimension (mm)			Inlet Size (a)	Outlet/close flow size (b)	Outlet/open flow size
							Length (L)	Width (W)	Height (H)			
JYFPCA-4-450	4	450	60	9	830	2.2	1960	700	900	DN50	DN50	G1/2
JYFPCA-8-450	8		120	19	920		2465					
JYFPCA-10-450	10		150	24	9800		2710					
JYFPCA-12-450	12		180	29	1010		2980					
JYFPCA-16-450	16		240	36	1120		3465					
JYFPCA-15-700	15	700	225	18	1710	2.2	2665	900	1100	DN65	DN50	G1/2
JYFPCA-20-700	20		300	24	1960		2970					
JYFPCA-30-700	30		450	37	2315		3610					
JYFPCA-40-700	40		600	49	2588		4500					
JYFPCA-30-870	30		450	23	2946		3280					
JYFPCA-40-870	40	870	600	30	3390	4.0	3670	1200	1300	DN80	DN65	G1/2
JYFPCA-50-870	50		750	38	3950		4210					
JYFPCA-60-870	60		900	46	4390		4650					
JYFPCA-80-870	80		1200	62	5330		5500					
JYFPCA-50-1000	50		745	29	3960		4060					
JYFPCA-60-1000	60	1000×1000	1050	35	4510	4.0	4810	1500	1400	DN80	DN65	G 3/4
JYFPCA-80-1000	80		1200	47	4968		5200					
JYFPCA-100-1000	100		1500	58	5685		5900					
JYFPCA-120-1000	120		1800	70	6320		6560					
JYFPCA-100-1250	100		1480	38	7960		5120					
JYFPCA-140-1250	140	1250 × 1250	2090	53	9050	5.5	6030	1800	1600	DN 125	DN 80	G3/4
JYFPCA-160-1250	160		2380	60	10490		6520					
JYFPCA-200-1250	200		2980	75	13060		7480					
JYFPCA-250-1250	250		3735	93	15850		8680					
JYFPCA-200-1500	200		2960	51	18300		6500					
JYFPCA-300-1500	300	1500 × 1500	4430	75	24130	7.5	8230	2200	1900	DN 200	DN 100	G 1
JYFPCA-350-1500	350		5190	87	27200		8670					
JYFPCA-400-1500	400		5950	101	30100		9980					
JYFPCA-500-1500	500		7460	125	36250		11660					
JYFPCA-600-2000	600		12000	87	45800		11200					
JYFPCA-700-2000	700	2000 × 2000	14000	101	49600	11.0	12350	3000	2600	DN	DN 125	G 1
JYFPCA-800-2000	800		16000	109	53100		13480					
JYFPCA-900-2000	900		18000	129	57900		14690					
JYFPCA-1000-2000	1000		20000	141	61500		15810					

Requirements for use of filter presses

1. According to the process requirements to make pipeline connection, and do water inlet test, detect the air tightness of the pipeline;
2. For the connection of the input power supply (3 phase + neutral), it is best to use a ground wire for the electric control cabinet;
3. Connection between control cabinet and surrounding equipment. Some wires has been connected. The output line terminals of the control cabinet are labeled. Refer to the circuit diagram to check the wiring and connect it. If there is any looseness in the fixed terminal, compress again;
4. Fill the hydraulic station with 46 # hydraulic oil, the hydraulic oil should be seen in the tank observation window. If the filter press operates continuously for 240 hours, replace or filter the hydraulic oil;
5. Installation of cylinder pressure gauge. Use a wrench to avoid manual rotation during installation. Use an O-ring at the connection between the pressure gauge and the oil cylinder;
6. The first time the oil cylinder runs, the motor of the hydraulic station should be rotated clockwise (indicated on the motor). When the oil cylinder is pushed forward, the pressure gauge base should discharge air, and the oil cylinder should be repeatedly pushed forward and backward (the upper limit pressure of the pressure gauge is 10Mpa) and air should be discharged simultaneously;
7. The filter press runs for the first time, select the manual state of control cabinet to run different functions respectively; After the functions are normal, you can select the automatic state;
8. Installation of filter cloth. During the trial operation of the filter press, the filter plate should be equipped with filter cloth in advance. Install the filter cloth on the filter plate to ensure that the filter cloth is flat and there are no creases or overlaps. Manually push the filter plate to ensure that the filter cloth is flat.
9. During the operation of the filter press, if an accident occurs, the operator presses the emergency stop button or pulls the emergency rope;

Main faults and troubleshooting methods

Fault phenomenon	Reasons	Troubleshooting
Severe noise or unstable pressure in the hydraulic system	1. The oil pump is empty or the oil suction pipe is blocked.	Oil tank refueling, solve suction pipe leakage
	2. The sealing surface of the filter plate is caught with misc.	Clean sealing surfaces
	3. Air in the oil circuit	Exhaust air
	4. Oil pump damaged or worn	Replace or repair
	5. The relief valve is unstable	Replace or repair
	6. Pipe vibration	Tightening or reinforcing
Insufficient or no pressure in the hydraulic system	1. Oil pump damage	Replace or repair
	2. Pressure adjusted incorrectly	Recalibration
	3. Oil viscosity is too low	Replacement of oil
	4. There is a leak in the oil pump system	Repair after examination
Insufficient cylinder pressure during compression	1. Damaged or stuck high pressure relief valve	Replace or repair
	2. Damaged reversing valve	Replace or repair
	3. Damaged large piston seal	replacement
	4. Damaged small piston "O" seal	replacement
	5. Damaged oil pump	Replace or repair
	6. Pressure adjusted incorrectly	Recalibrate
Insufficient cylinder pressure when returning	1. Damaged or stuck low pressure relief valve	Replace or repair
	2. Damaged small piston seal	replacement
	3. Damaged small piston "O" seal	replacement
Piston crawling	Air in the oil circuit	Replace or repair
Serious transmission noise	1. Bearing damage	Replacement
	2. Gear striking or wearing	Replace or repair

Serious leakage between plates and frames	1. Plate and frame deformation	Replacement
	2. Debris on sealing surface	Clean
	3. Filter cloth with folds, overlaps, etc.	Qualified for finishing or replacement
	4. Insufficient compression force	Appropriate increase in compression force
The plate and frame are broken or deformed	1. Filter pressure too high	turn down the pressure
	2. High material temperature	Appropriately lowered temperatures
	3. Compression force too high	Adjust the compression force appropriately
	4. Filtering too fast	Reduced filtration rate
	5. Clogged feed hole	Cleaning the feed hole
	6. Stopping in the middle of filtration	Do not stop in the middle of filtration
The replenishment system works frequently	1. The hydraulic control check valve is not tightly closed	replacement
	2. Leakage in the cylinder	Replacement of cylinder seals
Hydraulic reversing valve failure	Spool stuck or damaged	Disassemble and clean or replace the directional valve
The trolley can't be pulled back because of the back and forth impact.	1. Low oil motor oil circuit pressure	adjust
	2. The pressure relay pressure is low	adjust

Failure to follow procedures	Failure of a component of the hydraulic system, electrical system	Repair or replace symptomatically after inspection
Diaphragm damage	1. Insufficient air pressure	Reduced press pressure
	2. Insufficient feed	Pressing after filling the chamber with material
	3. A foreign object has punctured the diaphragm.	foreign matter removal
Bending damage to main beam	1. Poor or uneven foundations	Refurbish or redo

Welcome to inquiry!

Shanghai Junyi Filter Equipment Co., Ltd.

Tel. +86 021-51863216

Phone: +8613916993659

Email: junyifilter@junyigl.com

Address: Shanghai, China

Website: www.junyifilter.com